

Optional accessory:

VIDEOMASTER USB
(Camera module)

Lacquer and Paint Testing Machine Model 202 EM



testing equipment for quality management

ERICHSEN

Technical Description

ERICHSEN
Cupping Test

**DIN EN ISO,
BS, NF, SIS**

Equipped with
electromotive
drive and laterally
opened cylinder

Product

Lacquer and Paint Testing Machine, Model 202 EM, with electromotive drive, equipped with a laterally opened test head, test tool in accordance with DIN EN ISO 1520, electric installation for connecting the illumination of the microscope as well as a digital display for the acquisition of the ERICHSEN cupping value, with integrated preselection counter for setting the maximum cupping value required.

Application

This simple to operate Lacquer and Paint Testing Machine is used for rapid and accurate measurement of the elongation and adhesion properties of protective paints and other coatings of all types using the

ERICHSEN CUPPING TEST

in accordance with

DIN EN ISO 1520
BS 3900 : Part E4
NF T 30-019
SIS 18 41 77

on sheet metal specimens up to 1.5 mm thick and max. 100 mm width.

The ERICHSEN Cupping Test provides valuable information on the suitability of a coating material for application in practise. Low cupping test values mean that the coated product may not withstand elongation stresses arising, resulting in corrosion of the substrate.

Model 202 EM is versatile and can be further enhanced by the various accessories available. The machine is a valuable tool for the quality control both for producers of paints and coating materials and for users .

Principle of the Test

The **Lacquer and Paint Testing Machine, Model 202 EM**, is a bench mounted unit with a sheet steel housing, test cylinder and operator's control panel.

The coated specimen panel is entered into the opening of the test cylinder with the coated surface facing upwards. Due to the laterally opening of the cylinder also larger sheet metal panels can be accommodated in the test head. On **Model 202 EM** the sheet metal specimen is clamped automatically using a separate clamping piston.

The cupping speed is infinitely variable from 2 mm/min to 60 mm/min or using a reversible potentiometer to set permanently to 0.2 mm/s.

The functions "DRAWING" and "RETURN" are initiated by pressing a push button.

The surface of the specimen is subjected to bilateral bending and elongation in all directions during the cupping process.

As soon as the first crack appears on the surface the movement of the ball punch is stopped by pushing a button. The ERICHSEN Cupping Depth reached can then be read off on a digital counter.

On completion of the test both the drawing and the clamping piston return to their starting positions, and the specimen panel can be taken out of the test head.

The system of the Lacquer and Paint Testing Machine, **Model 202 EM**, is secured by a limit switch and an overload protection, when reaching the final position.

Accessories

Special Test Tool

For special cases the standard cupping test tool to DIN EN ISO 1520, which has a 20 mm diameter ball punch, can be exchanged against a special test tool (Test Tool No. 11) with an 8 mm diameter ball punch. This tool is used in cases where only narrower sheet metal specimens (30 mm to 55 mm wide) are available for testing.

Microscopes for observing the test procedure

For the purpose of observing the test area and deciding when a crack has formed, the use of a microscope with integrated illumination is recommended. Before the forming process has started the microscope is focused on the illuminated surface. It is not necessary to adjust the microscope during the cupping process as the microscope holder moves in synchronisation with the drawing piston.



Lacquer and Paint Testing Machine, **Model 202 EM**, with **Stereo Microscope**

Electric Measuring Device

This piece of auxiliary equipment is intended for objective and accurate electric measurement of the destruction of coatings based on the Erichsen Cupping Test. If the system is ordered in conjunction with a machine the control gear and the measuring instrument are mounted directly into the housing of the **Model 202 EM**.

If the limit of ductility, i. e. the residual deformability of the lacquer, has been achieved, this is visually displayed on a LED. During the test a conducting fluid moistens the coated surface of the test panel and penetrates even the finest cracks in the coating. Once the conducting fluid meets the metal surface of the cup an appropriate reading indicates the degree of cracking.

During the Cupping Test, the smallest deflection on the display instrument signals the instant when pores have formed through the coating. The ERICHSEN Cupping Test value reached at this point represents the limit of elongation of the coating, from the point of view of its ability to act as a protection against corrosion.

Camera modul VIDEOMASTER USB

(see photograph on the front page)

The **VIDEOMASTER USB** (resolution 1.3 megapixel) is a camera module for visual observation of lacquered and coated surfaces during the cupping process, and is provided for use with a PC equipped with an interface USB 2 only. The power supply for the camera and the illumination is effected through the USB 2 connection (300 mA). Due to the magnetic fixing device of the camera module and the preset (focused) objective, the **VIDEOMASTER USB** is immediately ready for use.

System requirements: Processor of at least 1.3 GHz, 256 MB RAM, 32 MB graphics, 20 MB unoccupied fixed-disk memory capacity, 1 free USB 2 port, operating system WIN 2000/XP.

The **VIDEOMASTER USB** can also be retrofitted to an existing Lacquer and Paint Testing Machine, Model 202 EM or 202 C.



Lacquer and Paint Testing Machine, **Model 202 EM**, with **VIDEOMASTER USB**

Technical Data

(Basic machine Model 202 EM)

Dimensions: Width: 430 mm
Depth: 430 mm
Height: 380 mm

Weight, net: approx. 80 kg

Mains connection: 230 V , 50 Hz
(110 V, 60 Hz upon request)

Depth of draw display:
(Preselection counter) digital
(accuracy 0.1 mm)

Drawing speed: 2 mm/min to
60 mm/min
(infinitely variable)
(0,2 mm/s permanently)

| Order Information | |
|--|--|
| Ord.-No. | Product Description |
| 0284.01.31 | Lacquer and Paint Testing Machine, Model 202 EM , with electromotive drive and a laterally opened test head |
| <i>The scope of supply includes:</i> <ul style="list-style-type: none">◆ Test Tool No. 27◆ Operating instructions | |

| Accessories | |
|-------------|--|
| Ord.-No. | Product Description |
| 0001.01.32 | Test Tool No. 11 acc. to EN ISO 20482, for strips 30 - 55 mm wide and 0.1 - 1 mm thick, consisting of ball punch 8 mm Ø, drawing die and sheet holder ring |
| 0004.01.32 | Test Tool No. 27 acc. to EN ISO 20482 and DIN EN ISO 1520 (spare part), consisting of ball punch 20 mm Ø, drawing die with 27 mm bore and blank holder |
| 0235.01.32 | Special Microscope with holder and Illumination, 10-fold magnification and 17.5 mm field of vision |
| 0237.01.32 | Stereo Microscope with holder and Illumination, 10-fold magnification and 18 mm field of vision |
| 0493.01.32 | VIDEOMASTER USB Camera module for visual observation of lacquered and coated surfaces during the Cupping Test |
| 0016.01.32 | Electric Special Measuring Device For accurate measurement of the breakdown of the lacquer film during the Erichsen Cupping Test |

Subject to technical modifications.
Group 1 - TBE 202 EM – IV/2009

ERICHSEN Cupping Test Values specified in the Conditions of Purchase for Surface Coatings by some German Public Authorities

DEUTSCHE BAHN AG, TL 918 300 (Technical conditions of purchase for coating materials)

The Cupping Test is conducted on 1 mm thick sheet metal specimen strip after 3 days drying. The cupping test is repeated after ageing at elevated temperature, on another part of the specimen.

Ageing: The specimen panel is held at 100°C for 3 hours, and is then allowed to cool for 1 hour at room temperature.

| Coating Material | Cupping Test values in mm | |
|---|---------------------------|--------------|
| | Before Ageing | After Ageing |
| Phthalate resin coating | 6 | 6 |
| Phthalate resin coating, silk finish | 4 | 4 |
| Quick drying synthetic resin coatings | 6 | 4 |
| Nitro combination coatings and coatings for rail vehicles | 6 | 6 |
| Acid hardened clear lacquers | 6 | ⌚ |
| Nitro combination coatings for road vehicles | 4 | 4 |
| Metal primers | 6 | ⌚ |
| Stoving paints | after stoving | 4 |
| Dip coatings | 6 | 4 |

FEDERAL MINISTRY OF DEFENCE, VTL 7100-002 (Interim Technical Conditions of Purchase)

The treatment of surfaces of accommodation equipment made of steel:

Requirement: The Erichsen Cupping Test Value (DIN ISO 1520) must not be less than 3 mm.

DEUTSCHE TELECOM AG, KPZ (X) 41430/1

Coating materials for equipment for Deutsche Telekom AG (Coating thickness 20 µm, sheet thickness 1 mm):

| | | | |
|----|--|----------------------------|----------|
| a) | before heat treatment | Cupping Test Value: | |
| | Oil and chlorine rubber coatings | | 10 mm |
| | Synthetic resin coatings - air drying | | 8 mm |
| | - stove drying | | 6 mm |
| | Nitro coatings and combination coatings depending on specified drying time | | 4 - 6 mm |
| b) | after ageing at elevated temperature (72 hours drying, including 3 hours at 100°C) | | |
| | Oil and chlorine rubber coatings | | 8 mm |
| | Synthetic resin coatings - air drying | | 6 mm |

The special coatings used for sheet aluminium must reach the following cupping test values on 1 mm thick sheet metal specimens, as a minimum:

| | | | |
|----|---------------------------------------|--|--------|
| a) | before ageing at elevated temperature | | |
| | - air drying | | 4 mm |
| | - stove drying | | 3 mm |
| b) | after ageing at elevated temperature | | |
| | - air drying | | 3.5 mm |